



Rebooting Micros Workstation 4/4LX

- WS4 and WS4LX

1. When facing the touch screen side of the WS4:



The power button is under the power light. Tilt workstation back:



To reboot the workstation using the power button simply hold the button down for approx 10 seconds. Once the workstation is off push and release the power button.

2. To reboot the workstation using the power cord (not recommended, should be last resort only!) simply unplug the power cord from the wall for 10 seconds and then plug it back in. The workstation will usually load automatically. If this does not happen push and release the power button.